## SONY

## PWSK-4403

#### PWS-4403 Control Panel



#### Overview

PWSK-4403 USB Control Device integrates with the PWA-PRC1 Production Control Software. It is used to control slow-motion replay of live video and other functions. It is equipped with the control buttons, jog dial, and fader lever that are required to control slow-motion replay on the PWS-4400.

The PWSK-4403 is the USB control device that is used in conjunction with the PWA-PRC1 Production Control application. It controls slow-motion replay, clip management, and playlist editing.

Button layout designed for ease of use

Familiar operation to other slow motion control panels

# Related products

PWS-110MG1

Short-depth Media Gateway Workstation PWS-110PR1

Short-depth Production Control Workstation PWS-100MG1

Media Gateway Workstation PWS-110CM1

Content Management Station

# SONY

### Gallery



