

## BVMK-P1710

Protection panel for BVM-HX1710 and BVM-HX1710N.

### Overview

#### **Protection panel for BVM-HX1710/BVM-HX1710N 16.5-inch 4K TRIMASTER HX master monitor**

The BVMK-P1710 accessory is a protection panel for the BVM-HX1710/BVM-HX1710N 16.5-inch monitor—safeguarding the premium LCD screen from scratches and impacts during transportation and preparation.\* The BVMK-P1710 is easy and quick to attach and detach, without the need for any tools. Where a BVMK-P1710 is attached, panel damage is reduced and there is a far lower incidence of panel replacement and downtime—of particular significance during rental cycles, for example. The BVMK-P1710 optional protection panel can also be mounted together with the mounting bracket BVMK-M1710.\*\*

\*The optional protection panel cannot be used in operation for avoiding any thermal problems with the monitor.

\*\* A front bezel of the BVM-HX1710 or BVM-HX1710N is projected from a front surface of a 19-inch EIA standard rack for attaching and detaching the protection panel BVMK-P1710. Clearance space at the top and/or bottom of the monitor may be required to enable attachment and detachment.

### Features

The BVMK-P1710 protection panel is designed to fit precisely on the BVM-HX1710/BVM-HX1710N monitor's front surface. The premium LCD screen of the BVM-HX1710/BVM-HX1710N is protected from inadvertent scratches and shocks during transportation and preparation.

## **Simple attachment/detachment mechanism**

The protection panel grips the monitor from the upper side and holds it using spring stoppers on the lower side of the screen bezel. No tools are required—the spring stoppers of the protection panel are released to attach and detach.

## **Use with rack-mounted monitor**

The BVMK-P1710 optional protection panel can be mounted together with the rack-mount bracket BVMK-M1710.\*

\* A front bezel of the BVM-HX1710 or BVM-HX1710N is projected from a front surface of a 19-inch EIA standard rack for attaching and detaching the protection panel BVMK-P1710. Clearance space at the top and/or bottom of the monitor may be required to enable attachment and detachment.