

BVM-F250

24.5-inch Full-HD Broadcast
OLED Monitor



Overview

Broadcast reference monitor

For reference monitoring applications in the broadcast industry, Sony's leading edge Organic Light-Emitting Diode (OLED) technology and signals processing technology ensures absolutely outstanding performance with the BVM-F250.

Affordable price

Super Top Emission technology enhances OLED's intrinsic benefits to deliver outstanding black performance, a quick response with virtually no motion blur, and a wide colour gamut. An all-new 12-bit output digital signal processing engine provides a nonlinear cubic conversion colour-management system that delivers precise colour reproduction, stunning picture uniformity, smoother-than-ever gamma performance, and picture quality consistency.

Accepts computer signals via HDMI

The BVM-F250 accepts various computer signals input up to 1920 x 1080 through its HDMI connector.

Features

Superb Picture Performance

Sony TRIMASTER EL technology combines the ultimate performance of Sony OLED display with the highly sophisticated

TRIMASTER technology to provide the highest level of picture performance:

- Accurate Black Reproduction
- High purity and accurate colour reproduction
- Quick response with virtually no motion blur
- High Contrast Performance

Super Top Emission™ technology

Sony's Super Top Emission™ technology has a micro-cavity structure which incorporates colour filters. The micro-cavity structure uses an optical resonance effect to enhance colour purity and improve light-emission efficiency. In addition, the colour filter of each RGB further enhances the colour purity of emitted light, and reduces ambient light reflection.

Ultimate Display Engine

High-precision signal processing engine has been developed to fulfil the reference monitor criteria and is optimized to maximize OLED panel performance. This engine incorporates 12-bit output accuracy at each process, and provides both a high quality I/P conversion algorithm and a highly accurate colour management system.

Multi-format signal support

The BVM-F250 monitor can accept almost any SD or HD video format, both analogue and digital, and variable computer signals up to 1920 × 1080. In addition to the standard inputs, four option board slots are offered to configure this monitor according to different user needs.

Versatile video inputs

This monitor is equipped as standard with two 3G/HD/SD-SDI inputs, an HDMI (with HDCP) input and a Displayport* for future expansion. In addition, four option ports are available.

* DisplayPort input will be supported from monitor software

version 1.1 or later.

Four Slots for Optional Video Input Decoders

The monitor can accept up to four optional video input boards simultaneously. Available formats include analogue, composite, Y/C, components, RGB and digital 3G/HD/SD SDI.

3D signal analyzing functions (3D signal input, 2D display)

By installing the optional BKM-250TG 3G/HD-SDI input adaptor*, the BVM-F250 can support a variety of 3D signal analyzes. The 3D signals* are displayed in 2D mode.

- Difference display
- Checkerboard display
- L/R switch display
- Horopter check display
- Flip H display

* Requires the BKM-250TG 3G-SDI input adaptor (serial number 7200001 or later). 3D signals are not displayed in stereoscopic view.

Auto White Balance

The colour temperature and white balance of BVM-E and F Series monitors can be automatically adjusted by the Auto White Balance function using specified colour temperature probes, such as the Konica Minolta CA-210, CS-200, DK-Technologies PM5639/06, and X-Rite i1 (Eye-One) Pro.

High Quality I/P Conversion Technology

The BVM-F250 monitor uses a sophisticated I/P conversion technique that keeps artefacts that are often seen in flat panel displays to a minimum such as edge jaggedness, conversion errors, etc.

Low video delay

The BVM-F250 display engine ensures a picture delay that is less than one field.

Panel Calibration

Every BVM-F250 monitor is carefully calibrated at the factory on an individual basis, providing a high level of accuracy and stability for characteristics such as gamma and uniformity.

Colour Feedback System

Using a colour feedback system, the BVM-F250 monitor achieves the stability required for Broadcast critical monitoring applications.

Interlaced Display Mode

Faithfully reproduces interlaced signals, emulating CRT monitors.

Picture &

Two images can be displayed Side by Side to provide users with enhanced operational flexibility.

Pixel Zoom Mode

A selected area of the displayed picture can be enlarged on a pixel basis, up to eight times in size both vertically and horizontally.

HD Frame Capture Mode

The HD Frame Capture function of the BVM-F Series allows a picture frame from the 3G-SDI and HD-SDI input to be captured and saved as a picture file on a Memory Stick™ media.

Separate Control unit with memory stick slot

A separate control unit BKM-16R is available for the BVM-F250. It is equipped with a Memory Stick socket enables users to download and save all monitor set-ups such as input channel configuration, control preset adjustments, white balance settings and maintenance parameters.

Centralised Monitor-Wall Control

Multiple monitors can be easily managed by a single control unit BKM-16R via an Ethernet connection.

Specifications

Picture Performance	
Panel	OLED panel
Picture Size (Diagonal)	623.4 mm
Picture Size (Diagonal)	24 5/8 inches
Effective Picture Size (H x V)	543.4 x 305.6 mm
Effective Picture Size (H x V)	21 1/2 x 12 1/8 inches
Resolution (H x V)	1920 x 1080 pixels (Full HD)
Aspect	16:9
Pixel Efficiency	0.9999
Panel Drive	RGB 10-bit
Panel Frame Rate	48 Hz, 50 Hz, 60 Hz, 72 Hz, 75 Hz (The values for dimensions are approximate.)
Viewing Angle (Panel)	89°/89°/89°/89° (typical) (up/down/left/right contrast >

Specification)	10:1)
Normal Scan	0% scan
Native Scan	Mapping the pixels of the signal to the panel to one-to-one mode, or displaying an SD signal of nonsquare pixels (the number of H pixels of the signal system is 720 or 1440) or a 640 × 480 SD signal of HDMI video by scaling processing of doubling for the V direction and correct aspect ratio for the H direction and also optimizing and displaying a picture by modifying the aperture coefficient value, filter coefficient value, etc.
Under Scan	3% under scan
Over Scan	Mask of 5% over scan portion in the normal scan
Color Temperature	D65, D93, User
Standard Luminance	100 cd/m ² (Preset1 to Preset5)
Standard Luminance	(100% white signal input)
	ITU-R BT.709, EBU, SMPTE-C, F250 Native (The PVM-L1700 individual chromaticity points. The widest

Color Space (Color Gamut)	color space setting of the signal is reproduced by the PVM-L1700. R (x = 0.645, y = 0.330)/G (x = 0.267, y = 0.634)/B (x= 0.150, y= 0.060) (typical))
---------------------------	---

Warm-up Time	Approx. 30 minutes
--------------	--------------------

Input

SDI Input	BNC (x2) Input impedance: 75 Ω unbalanced
-----------	---

SDI Input	
-----------	--

SDI Input	3G-SDI:
-----------	---------

SDI Input	- Y/Cb/Cr (4:2:2): 148.5 MHz/74.25 MHz/74.25 MHz
-----------	--

SDI Input	- Y/Cb/Cr (4:4:4): 148.5 MHz /148.5 MHz/148.5 MHz
-----------	---

SDI Input	- G/B/R (4:4:4): 148.5 MHz/148.5 MHz/148.5 MHz
-----------	--

SDI Input	HD-SDI:
-----------	---------

SDI Input	- Y/Cb/Cr (4:2:2): 74.25 MHz/37.125 MHz/37.125 MHz
-----------	--

SDI Input	SD-SDI:
-----------	---------

SDI Input	- Y/Cb/Cr (4:2:2): 13.5 MHz/6.75 MHz/6.75 MHz
SDI Input	
SDI Input	3G-SDI: 10bit/sample, 12 bit/sample
SDI Input	HD-SDI: 10bit/sample
SDI Input	SD-SDI: 10bit/sample
HDMI Input	HDMI (x1) (HDCP correspondence, Deep Color correspondence)
DisplayPort	DisplayPort connector (x1) (The BVM-F170 individual chromacity points. The widest color space setting of the signal is reproduced by the BVM-F170. R (x=0.681, y=0.319)/G (x=0.189, y=0.724)/B (x=0.141, y=0.051) (typical))
Option Port	Four (4) ports
Parallel Remote	D-sub 9-pin (female) (x1)
Serial Remote (LAN)	RJ-45 (x1) (Ethernet, 10BASE-T/100BASE-TX)

Output

SDI Output	BNC (x1) (monitor output) (For displaying the color gamut of the wide color space mode S-GAMUT, which is available for the F23 or F35 Digital Cinematography Camera.)
SDI Output	Output signal amplitude: 800 mVp-p ± 10%
SDI Output	Output impedance: 75 Ω unbalanced
SDI Output	Transmission distance
SDI Output	3G-SDI: 70 m max. (The signal from the monitor output connector does not satisfy the online signal specifications.)
SDI Output	HD-SDI: 100 m max. (The signal from the monitor output connector does not satisfy the online signal specifications.)
SDI Output	SD-SDI: 200 m max. (When using 5C-FB coaxial cables (Fujikura or equivalent).)
DC 5V Output	Circle 4-pin (female) (x1)

General

Power Requirements	100 V to 240 V AC, 1.6 A to 0.8 A, 50/60 Hz
Power Consumption	Approx. 145 W (max.)
Power Consumption	Approx. 72 W (average power consumption in the default status)
Inrush Current	(1) Maximum possible inrush current at initial switch-on (Voltage changes caused by manual switching): 53 A peak, 17 A r.m.s. (240V AC)
Inrush Current	(2) Inrush current after a mains interruption of five seconds (Voltage changes caused at zero-crossing): 39 A peak, 6 A r.m.s. (240V AC)
Operating Temperature	0°C to 35°C (Recommended: 20°C to 30°C)
Operating Temperature	32°F to 95°F (Recommended: 68°F to

	86°F)
Operating Humidity	0% to 90% (no condensation)
Storage/Transport Temperature	-20°C to +60°C
Storage/Transport Temperature	-4°F to +140°F
Storage/Transport Humidity	0% to 90%
Operating/Storage/Transport Pressure	700 hPa to 1060 hPa
Dimensions (W x H x D) [*1]	576.0 x 424.0 x 148.0 mm
Dimensions (W x H x D) [*1]	22 3/4 x 16 3/4 x 5 7/8 inches
Mass	Approx. 13.0 kg
Mass	Approx. 28 lb 11 oz
Supplied Accessories	AC power cord (1)
Supplied Accessories	AC plug holder (1)
Supplied Accessories	Bracket (1)
Supplied Accessories	Operation Manual (Japanese, English, each 1)

Supplied Accessories	CD-ROM (1)
Supplied Accessories	Using the CD-ROM Manual (1)
Optional Accessories	BKM-16R Monitor Control Unit
Optional Accessories	BKM-37H/BKM-38H Controller Attachment Stand
Optional Accessories	SMF-700 Monitor Interface Cable
Optional Accessories	BKM-220D SDI 4:2:2 Input Adaptor (with serial number 2100001 or higher)
Optional Accessories	BKM-227W NTSC/PAL Input Adaptor
Optional Accessories	BKM-229X Analog Component Input Adaptor (with serial number 2200001 or higher)
Optional Accessories	BKM-243HS HD/D1-SDI Input Adaptor (with serial number 2108355 or higher)
Optional Accessories	BKM-244CC HD/SD-SDI

Closed Caption Adaptor

Optional Accessories

BKM-250TG 3G/HD/SD-SDI
Input Adaptor (with serial
number 7300001 or higher)

Notes

Note

[*1] The values for dimensions are
approximate.

Gallery

